

INITIALS AND THEIR MEANINGS



VESSEL IDENTIFICATION INFORMATION

MMSI = Maritime Mobile Service Identity = [Κωδικός Αναγνωρίσεως της Ναυτικής Κινητής Υπηρεσίας](#)

CALL SIGN = a designated sequence of letters and numbers that are assigned when a vessel receives its ship-radio licence, in order to be **uniquely identified** = [Διεθνές Διακριτικό Σήμα](#)

ROUTINE TRAFFIC OPERATION EXCHANGE

ETA = estimated time of arrival

IMO NUMBER = ship identification number. Permanent 7 digit identification number issued to commercial ships and registered ship management companies on behalf of the IMO (International Maritime Organization).

PILOT STATION = in shipping = designated location at sea where maritime pilots board a vessel to provide guidance through complex waters when into or out of port.

INITIALS AND THEIR MEANING

GMDSS = Global Maritime Distress and Safety System = [Παγκόσμιο Ναυτιλιακό Σύστημα Κινδύνου και Ασφαλείας](#)

SWL = Safe Working Load = [Φορτίο Ασφαλούς Εργασίας \(μέγιστο φορτίο ανυψωτικών\)](#)

CPA = Closest Point of Approach = [Πλησιέστερο Σημείο Προσέγγισης](#)

INITIALS AND THEIR MEANINGS

EPIRB = Emergency Position Identification Radio Beacon = Ραδιοφάρος
Ενδείξεως Στίγματος Έκτακτης Ανάγκης

ETA= Estimated Time of Arrival= Εκτιμώμενος Χρόνος Άφιξης

RCC=Rescue Coordination Centre= Κέντρο Συντονισμού Διάσωσης

VTS= Vessel Traffic Services= Υπηρεσίες Κυκλοφορίας των Πλοίων (για βελτίωση
και αποτελεσματικότητα της κυκλοφορίας των πλοίων)

TSS= Traffic Separation Scheme= Σύστημα Διαχωρισμού της Κυκλοφορίας
(καθιέρωση λωρίδων θαλάσσιας κυκλοφορίας κ.ά.)

